


How to Interpret the Results of the T4 Integrity Tests

A series of diagnostic tests can be performed to check the integrity of the T4 hardware. The test results will be displayed after each test has been completed. The different types of integrity test available are described below:



```

Testing CD Drive ..... PASS
Testing LAN Card ..... Not Present
Checking for Parallel Device ..... Off-Line or Not Connected

Test Successful. Touch BLACK or WHITE to Test LCD Display.
    
```



Testing CD Drive

This test attempts to read from the Compact Disc that is currently loaded in the CD drive.

If the CD can be read successfully, the display screen will show a "PASSED" message.

If the test fails and the CD cannot be read, the message "Fail or No CD Found" will be displayed. A CD read failure could be caused by one of the following conditions:

- There is no CD in the CD drive (press the eject button to make sure).
- The CD has been inserted upside down in the CD drive. Ensure the label side of the CD is face up.
- The CD is dirty or scratched. (see "CD Cleaning Procedure").
- The CD is defective. Try using another CD, if it works, replace the defective CD.
- The drive may be malfunctioning. Check all the above and repeat the test for confirmation that there is a CD drive problem.

Testing LAN Card

For units containing a correctly operating LAN card, the message "Present" will be shown on the completion of the test.

If a LAN card is not included, the message "Not Present" will be shown.



NOTE: The LAN (Local Area Network) facility is intended for potential future developments in dealership systems, and is not currently in use.

Checking for Parallel Device

This test verifies the connection to a printer.

If no printer is connected, a message "Not Connected" will be displayed.

If a printer is connected to T4 which is powered OFF and On-line, the message "Connected" will be displayed.

If a printer is connected to T4 and the message "Off-Line or Not Connected" is displayed, check the following:

- Is the printer On-Line? The indication light on the printer labelled "On-Line" should be lit. If not, press the On-Line button on the printer.
- If the printer does not come on-line, try resetting the printer by turning it OFF then back ON. Select BLACK or WHITE to TEST LCD DISPLAY.
- If an error code appears on the printer, refer to the User's Manual that was supplied with the printer for an explanation of the printer error message.
- Check the cable between T4 and the printer to make sure it is plugged in securely.
- Check the Configuration Module to make sure T4 is set up to use the printer. The Configuration Screen can be accessed by selecting the "Configuration" option button on the "Welcome Screen". See "Set Printer/Paper" in the T4 Configuration section of the on-line details.